

INTRODUCTION	1	WIRE COLOR CODE	12
WEIGHT RESTRICTIONS	3	Maximum Current Allowable in Low Voltage Wiring	12
Regulations and Requirements	3	Exhaust System	12
Gross Axle Weight Rating	3	Fuel System	12
Weighing the Vehicle	3	Rear Comb. Lamp/License Plate Lamp Mounting Bracket	12
Tire Inflation	3	Serviceability	13
Center of Gravity	3	Wheelbase Alteration	13
INSTALLATION OF BODY AND SPECIAL EQUIPMENT	4	Shortening/Lengthening the Wheelbase without Altering the Frame	13
Clearance Around Engine, Driveline and Others	4	Altering the Wheelbase by Altering the Frame	13
Engine	4	Glossary of Terms—Chassis Wheelbase Alteration	13
Transmission	4	1999 MODEL YEAR BODY APPLICATION SUMMARY CHART	17
Front and Center Propeller shafts	4	1999 MODEL YEAR* BODY & PAYLOAD WEIGHT DISTRIBUTION (% FRONT/% REAR)	18
Rear Propeller Shaft	5	1999 GM/ISUZU SERIES TRUCK PRODUCT ENGINES	20
Exhaust System Clearance	5	GVW/GCW Ratings	20
Rear Wheel and Axle Clearance	5	Clutch Engagement Torque Chart	21
Other Clearances	5	PAINT CODE NUMBERS FOR 1987–1995 W3500/W4500	22
Body Installation	6	PAINT CODE NUMBERS FOR 1995.5–1999 W3500/W4500	23
Installation of Special Equipment on the Chassis	6	PAINT CODE NUMBERS FOR 1997–1998 F SERIES MODELS (ZY1 PAINT SCHEME)	23
Subframe Design and Mounting	6	W3500, W4500, W5500 TOWING PROCEDURE	24
Contouring of Subframe	6	WEIGHT DISTRIBUTION	24
Prohibited Attachment Areas	7	Weight Distribution Formulas	26
Subframe Mounting Bracket Installation	7	Basic Formulas	26
Subframe Mounting U-bolt Installation	7	Weight Distribution Formulas in Words	27
Modification of the Chassis Frame	8	Recommended Weight Distribution % of Gross Vehicle Weight by Axle	30
Working on Chassis Frame	8		
Drilling and Welding	8		
Reinforcement of Chassis Frame	8		
Welding	9		
Fluid Lines	9		
Preparation of Additional Lines	9		
Installation of Additional Lines	9		
Electrical Wiring and Harnessing	10		
Wiring	10		

TRAILER WEIGHT	30	Vertical Center of Gravity Formula	34
Payload at Kingpin	31	Horizontal Center of Gravity Formula	35
Payload at Rear Tandem	31	INTERSTATE HIGHWAY SYSTEM LIMITS	36
Performance Calculations	32	Bridge Gross Weight Formula	36
Speed Formula	32	Bridge Formula Definitions	36
Grade Horsepower Formula	32	Consecutive Axle Weight	37
Air Resistance Horsepower Formula	32	Exception to the Bridge Formula	37
Engine Horsepower Formula	33	Other Federal Provisions	37
Gradeability Formula	33	FEDERAL BRIDGE FORMULA TABLE	38
Startability Formula	34		

W3500/W4500 DIESEL

SPECIFICATIONS	1	Formulas for Calculating Rear Width and Height Dimensions	10
VEHICLE WEIGHTS, DIMENSIONS AND RATINGS	2	SUSPENSION DEFLECTION CHARTS	11
Variable Chassis Dimensions	3	TIRE AND DISC WHEEL CHART	12
Dimension Constants	3	Tire	12
12,000 lb. GVWR Manual Transmission Model	3	Disc Wheel	12
14,500 lb. GVWR Manual Transmission Model	3	PROPELLER SHAFT	13
12,000 lb. GVWR with Aisin Automatic Transmission Model	3	PTO LOCATION, DRIVE GEAR AND OPENING INFORMATION	15
14,500 lb. GVWR with Aisin Automatic Transmission Model	3	Opening Diagram	16
Vehicle Weight Limits:	3	BRAKE SYSTEM SCHEMATIC	17
Model Descriptions	3	Vacuum Over Hydraulic	17
FRAME & CROSSMEMBER SPECIFICATIONS	4	1999 MODEL DIESEL FUEL FILLER	18
FRAME CHART	5	Installation Instructions	18
AUXILIARY VIEWS	6	INSTALLATION DRAWINGS OF FUEL FILLER HOSE	19
BODY BUILDER WEIGHT INFORMATION CHART	7	Drawing #1	19
Cab Tilt	7	Drawing #2	19
Center of Gravity	7	Drawing #3	20
FRONT AXLE CHART	8	Drawing #4	20
REAR AXLE CHART	9	Drawing #5	21
Definitions	10	Drawing #3	21

W3500/W4500 GAS

SPECIFICATIONS	1	FRONT AXLE CHART	8
VEHICLE WEIGHTS, DIMENSIONS AND RATINGS	2	REAR AXLE CHART	9
Variable Chassis Dimensions	3	Definitions	10
Dimension Constants 11,050 GVW	3	Formulas for Calculating Rear Width and Height Dimensions	10
11,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model Federal	3	SUSPENSION DEFLECTION CHARTS FOR W3500	11
11,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model California	3	SUSPENSION DEFLECTION CHARTS FOR W4500	12
Dimension Constants 14,050 GVW	3	TIRE AND DISC WHEEL CHART	13
14,050 lb. GVWR with 4L80-E Hydra-Matic Transmission Model California/Federal	3	Tire	13
Vehicle Weight Limits:	3	Disc Wheel	13
FRAME & CROSSMEMBER SPECIFICATIONS	4	PROPELLER SHAFT	14
FRAME CHART	5	BRAKE SYSTEM SCHEMATIC	16
AUXILIARY VIEWS	6	Vacuum Over Hydraulic	16
BODY BUILDER WEIGHT INFORMATION CHART	7	1999 MODEL GASOLINE FUEL FILLER	17
Cab Tilt	7	Installation Instructions (Revised)	17
Center of Gravity	7	Gas Filler Neck Installation (Rear View) 96" Wide Body	17
		GAS FILLER NECK INSTALLATION (TOP VIEW) 96" WIDE BODY .	18
		Gas Filler Neck Installation (Top View) 96" Wide Body	18

W5500 DIESEL

SPECIFICATIONS	1	FRONT AXLE CHART	8
VEHICLE WEIGHTS, DIMENSIONS AND RATINGS	2	REAR AXLE CHART	9
Variable Chassis Dimensions	3	Definitions	10
Dimension Constants	3	Formulas for Calculating Rear Width and Height Dimensions	10
16,500 lb. GVWR Manual Transmission Model	3	SUSPENSION DEFLECTION CHARTS	11
16,500 lb. GVWR Automatic Transmission Model	3	TIRE AND DISC WHEEL CHART	12
Vehicle Weight Limits:	3	Tire	12
Model Descriptions	3	Disc Wheel	12
FRAME & CROSSMEMBER SPECIFICATIONS	4	PROPELLER SHAFT	13
FRAME CHART	5	PTO LOCATION, DRIVE GEAR AND OPENING INFORMATION	15
AUXILIARY VIEWS	6	Opening Diagram	16
BODY BUILDER WEIGHT INFORMATION CHART	7	BRAKE SYSTEM SCHEMATIC	17
Cab Tilt	7	Vacuum Over Hydraulic	17
Center of Gravity	7		

SYMBOLS	1	FUSE BLOCK CIRCUIT	10
ABBREVIATIONS	2	REFERENCE TABLE OF FUSE	11
WIRING	3	RELAY LOCATION	12
Wire Color	3	RELAY LIST	13
Distinction of Circuit by Wire Base Color	3	CIRCUIT DIAGRAM AUXILIARY POWER SOURCE	14
Wire Size	3	CIRCUIT DIAGRAM ACCESSORY WIRING	15
GROUNDING POINT LOCATION	4	CIRCUIT DIAGRAM HORN AND BACK-UP LIGHT	16
REFERENCE TABLE OF GROUNDING POINT	5	CIRCUIT DIAGRAM ENGINE STOP MOTOR	17
BODY ROOM LIGHT, ID & MARKER LAMP		CIRCUIT DIAGRAM TURN, HAZARD & STOP LAMPS	18
CONNECTOR LOCATION	6	CIRCUIT DIAGRAM INSTRUMENT PANEL	19
CIRCUIT DIAGRAM BODY ROOM LIGHT	7	FUEL TANK SENDING UNIT RESISTANCE	20
CIRCUIT DIAGRAM BODY ID & MARKER LIGHTS	8		
FUSE AND FUSIBLE LINK LOCATION	9		
Fuse Label	9		

SYMBOLS	1	RELAY LIST	14
ABBREVIATIONS	2	CIRCUIT DIAGRAM AUXILIARY POWER SOURCE	15
WIRING	3	CIRCUIT DIAGRAM ACCESSORY WIRING	16
Wire Color	3	CIRCUIT DIAGRAM HORN & BACK-UP LIGHT	17
Distinction of Circuit by Wire Base Color	3	CIRCUIT DIAGRAM TURN SIGNAL, HAZARD & STOP LAMPS	18
Wire Size	3	CIRCUIT DIAGRAM INSTRUMENT PANEL	19
GROUNDING POINT LOCATION	4	FUEL TANK SENDING UNIT RESISTANCE	20
REFERENCE TABLE OF GROUNDING POINT	5	F-SERIES RELAY LOCATION	21
BODY ROOM LIGHT, ID & MARKER LAMP CONNECTOR LOCATION	6	DEDICATED BODY BUILDER ELECTRICAL CIRCUITS BEHIND ENGINE FOR F-SERIES	22
CIRCUIT DIAGRAM BODY ROOM LIGHT	7	DEDICATED BODY BUILDER ELECTRICAL CIRCUITS BEHIND ENGINE FOR F-SERIES	23
CIRCUIT DIAGRAM BODY ID & MARKER LAMPS	8	Under the Cab Connection	23
FUSE AND FUSIBLE LINK LOCATION	9	BODY-CHASSIS ELECTRICAL CONNECTORS	24
Fuse Label	9	WIRING DIAGRAM BODY MOUNTING CIRCUITS	25
FUSE BLOCK CIRCUIT	10	BODY BUILDERS HARNESS ELECTRICAL COMPONENT LOCATION TABLE	26
FUSIBLE LINK	11	Body Builder Inline Connector	26
REFERENCE TABLE OF FUSE	12		
RELAY LOCATION	13		