
BODY BUILDERS INSTRUCTIONS	1
Section 0 – General Instructions	1
Section 1 – Body	2
Conversions	3
Air Conditioning	3
Rear Air Conditioning	3
Section 2 – Frame	4
Holes	4
Welding	4
Alterations	5
Section 3 – Front Suspension	5
Section 4 – Rear Suspension	5
Section 5 – Brakes	6
Section 6 – Engine	6
Section 7 – Transmission	9
Section 8 – Fuel and Exhaust	9
Fuel Systems	9
Fuel Fill	9
Fuel Lines	10
Fuel Tank	10
Exhaust System	11
Section 9 – Steering	12
Section 10 – Tires	12
Section 12 – Electrical Battery and Battery Cables	13
Accessory Power Supply Feeds	15

BODY BUILDERS INSTRUCTIONS – *Continued*

Section 13 – Heating/Cooling	16
Valve Sources:	16
CHASSIS	
M/L 11005 General Arrangement, Exterior	17
M/L 11006 General Arrangement, Exterior	18
M/L 110(05, 06) General Arrangement, Interior	19
M/L 110(05, 06) General Arrangement, Interior	20
BODY	
M/L 110(05, 06F) Bumper, Tailgate and Dutch Door	21
M/L 110(05, 06) Seat Mounting Hole Locations	22
M/L 110(05, 06) Roof Rack Mounting	23
FRAME	
Refer to Chassis – General Arrangement	17-20
AXLE/SUSPENSION	
Refer to Chassis – General Arrangement	17-20
FUEL TANK	
Refer to Chassis – General Arrangement	17-20
EXHAUST	
Refer to Chassis – General Arrangement	17-20
ELECTRICAL	
Ordering Information	24

NOTE: This vehicle has two air bags – one air bag for the driver and another air bag for the right front passenger. To help prevent unwanted inflation, see GM Service Manual for Diagnostic and Service Procedures before performing any service.