

UI Bulletin #82f

Subject: Fast Idle (RPO UF3)
Models Years Affected: 2008 and beyond
Models Affected: Chevrolet Express Van and GMC Savana Van
 Chevrolet Silverado and GMC Sierra 2500HD and 3500HD Pickup Trucks with the following engine option codes LY6(g), L96(g), LC8(g), LGH(d), LML(d), LMM(d), LWN(d), L8T(g) and L5P(d)
 Additionally, the 2020 and newer Chevrolet Silverado 4500-6500 MD trucks with the L5D (d) engine.
Origination Date: October 10, 2009
Revision Date: January 25, 2021

ADVISORY:


This bulletin provides a description of the Fast Idle (UF3) option on...


- Silverado/Sierra 2500 – 6500 HD Chassis Cab and Pickup truck models
- Express/Savana Cargo, passenger and Cutaway van models.

To obtain Fast Idle capability you must order the following options (not available on vehicles with PTO):

- 1) Pickup/MD Trucks or Vans
 - a) 2500HD - 6500HD Pickup or Chassis Cab (Fast Idle is not available on 1500 models)
 - b) Passenger/Cargo/Cutaway Van (2500/3500/4500)
- 2) An LY6, LC8 L96 or L8T gas engines or, LGH, LML, LMM, LWN, L5P or L5D, diesel engines.
- 3) Cruise Control – RPO K34
- 4) Fast Idle – RPO UF3

NOTE: Fast Idle (RPO: UF3) can be added by the dealer at extra cost.





Fast Idle is controlled using the Cruise Control buttons located on the left-hand side of the steering wheel.

Required Initial Conditions

These conditions must be met for Fast Idle to work:

1. Park Brake must be set
2. Transmission/PRNDL must be in Park (P) or Neutral (N).
3. The Brake must not be pressed.
4. Vehicle Speed must be zero.

Enable (Turn ON) Fast Idle

After the Required Initial Conditions above have been met, you can Enable Fast Idle by pressing and releasing the Cruise Control “ON” switch, the LED indicator on the switch will illuminate.

Preset Fast Idle

After the Required Enable Conditions above have been met, you can engage Fast Idle by pressing and releasing the Cruise Control “SET” switch to achieve the single preset fast idle speed of 1000* or 1200* rpm **depending on vehicle model, year and engine application*

Disable (turn off) Actions

Any of these conditions will cancel Fast Idle:

1. Turn Cruise Off. Press and Release the Cruise Control “ON/OFF” switch.
2. Press and Release the Cruise Control “SET” switch while in high idle.
3. Press the brake pedal.
4. Press and Release the Cruise Control “CANCEL” switch.
5. Release the Park Brake.
6. Move the Transmission Shift Lever (PRNDL) from Park (P) or Neutral (N).
7. Apply the accelerator pedal greater than 25%

Adding Fast Idle (UF3)

Adding the Fast Idle (UF3) feature is accomplished by reprogramming the Vehicle’s Body Control Module (BCM). GM Dealers can acquire a new Vehicle Configuration Index (VCI) by contacting Techline Customer Support Center (TCSC). A support center consultant will create the new VCI with UF3 option as part of the vehicle option content.



UI Bulletin #82f

Note:

TCSC typically imposes an administrative fee on the dealers requesting the updated VCI and this fee may be passed onto the customer. This fee is in addition to the labor charges for the reprogramming of the vehicle.

The newly created VCI is readily available for use in the reprogramming of the vehicle's BCM. Dealers simply need to perform a programming event on the BCM to now add the feature/option.

Reminders:

- The vehicle to which the addition of UF3 is being added MUST have Cruise Control (K34) in order for the feature to be added.
- The feature's operation and control functions, once added to the vehicle, are as outline in the preceding sections of this bulletin.

006X